


Name of supplier	KW-Commerce GmbH
Address of supplier	Jägerstr. 41 10117 Berlin Deutschland
Model Identifier and other applicable models below	48521.01
48521.01 48521.02	 28 October 2021 Katharina Zelisko Business Unit Director

**Specific precautions that shall be taken when the model is assembled, installed, maintained or tested**

See user manual, disconnect from power supply before assembling or disassembling the parts of the

**Disposal recommendations at the end of the light source's life time (Directive 2012/19/EU)**

Translations and national adaptations are included in the user manual of the item, supplied with the light source or its containing product.

The Waste Electrical and Electronic Equipment (WEEE) Directive aims to minimise the impact of electrical and electronic goods on the environment, by increasing re-use and recycling and by reducing the amount of WEEE going to landfill. The symbol on this product or its packaging signifies that this product must be disposed separately from ordinary household wastes at its end of life. Be aware that this is your responsibility to dispose of electronic equipment at recycling centers in order to conserve natural resources. Each country should have its collection centers for electrical and electronic equipment recycling.

For information about your recycling drop off area, please contact your related electrical and electronic equipment waste management authority, your local city office, or your household waste disposal service.

Contained Light Source(s)	Pieces
48521_LS	1

Contained Separate Control Gear(s)	Pieces
EPS, DC-DC included in LS	

**Light Sources can be replaced by end-user or qualified persons?**

Non-replaceable

**Separate Control Gears can be replaced by end-user or qualified persons?**

NA

**Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing**

The product contains an external power supply and the light source contains the control gear with motion sensor and dimmer. Unplug and connect parts to be tested to a relevant power source.

拆卸步骤 Disassembly steps:

1. 撕掉底座防滑垫 Tear off the base non-slip mat



2. 取掉底座四颗螺丝 Remove the four screws from the base



3. 拆掉底座里电路板固定支架 Remove the fixing bracket of PCB in the base



4. 取下灯杆后壳 Remove the rear cover



5. 用螺丝刀取下屏幕显示控制电路板 Use a screwdriver to remove the control PCB of the screen display



6. 取下灯板前壳 Remove the front cover



7. 用螺丝刀取下灯板螺丝 Use a screwdriver to remove the screw of the LED module

